


RIA Spoke Resonator Cryomodule Designs


Joel Fuerst

Argonne National Laboratory



RIA Spoke Resonator Geometries




~63 3-gap cavities required for std.
driver design (9 modules)



170 4-gap cavities required for
alternative design (48 modules)





316L SS LHe vessel




- SS shell with CF flanges using commercial Cu gaskets
- straightforward TIG welded shell

Flange Design


- each cavity has 2 beam flanges (3.37" or 4.5" CF) and 3 side flanges (4.5" CF)
- 316L SS CF flanges brazed to Nb ring at 982 C using 82% Au, 18% Ni alloy (mp 949 C)
- excess Nb keeps temp below 700 C during ebeam weld, is machined away after welding





Displacement due to 15 psi load for alternative SS head geometries



Endwall displacements




ATLAS Positive Ion Injector Cryomodule




- Space efficient design
- Top loading
- Versatile
- Straightforward alignment capability

Design Evolution




- Based on ATLAS PII cryomodule
- Top loading
- Common vacuum vs. separate vacuums: cleanliness
- Length is driven by cost, handling issues


Design Evolution



- Cylindrical
- Common vacuum
- Top loading




Design Evolution




- Cylindrical
- Separate vacuums
- End loading

Box Cryomodule with Separated Insulating and Beam Vacuums




- Reconciles separate beam and insulating vacuum spaces with short module-to-module spacing
- Constructive feedback from JLab, DESY

Separate insulating and beam vacuums




- Angled end walls permit drop-in installation
- Valves isolate clean components during final assembly
- Cleanliness requirements on vacuum vessel are relaxed
- Allows use of multilayer insulation


Module-to-Module Detail




345 MHz $\beta=0.36$ Box Cryomodule



3-Spoke Cryomodules



$$\beta = 0.50$$



$$\beta = 0.62$$

Conclusions

- Box cryomodule concept builds on successful ATLAS PII design, end-loading cylindrical designs are proven at TTF, JLab, SNS, etc.
- Although rectangular shape is a good fit for a variety of drift tube cavity geometries, cylindrical may be more appropriate for spoke cavities
- Addresses gradient issue with separate beam vacuum and clean assembly techniques
- Preserves tight module-to-module spacing in a top- or end- loading design with separate vacuum systems